


## Door Window Guide Replacement (Rear C 105/Short Body)


### Removal Procedure



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the rear door glass. Refer to [Rear Side Door Window Replacement](#) .
3. Remove the power window regulator. Refer to [Door Window Regulator Replacement](#) .
4. Remove the rear door upper trim.
5. Remove the bolt and the rear window guide.

### Installation Procedure

**Notice:** Refer to [Fastener Notice](#) in the Preface section.



1. Install the rear window guide with the bolt.

#### Tighten

Tighten the rear window guide bolt to 10 N·m (89 lb in)

2. Install the rear door upper trim.
3. Install the power window regulator. Refer to [Door Window Regulator Replacement](#) .
4. Install the rear door glass. Refer to [Rear Side Door Window Replacement](#) .
5. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .