


Sunshade Replacement (C 105/Short Body)


Removal Procedure



1. Remove the sunshade bracket cover.
2. Remove the screws and the sunshade from the headliner.
3. Disconnect the vanity mirror electrical connector.
4. Remove the screw and the sunshade support from the headliner.

Installation Procedure

Notice: Refer to [Fastener Notice](#) in the Preface section.



1. Install the sunshade support to the headliner with the screw.

Tighten

Tighten the sunshade support screws 3 N·m (27 lb in).

2. Connect the vanity mirror electrical connector.
3. Install the sunshade bracket to the headliner with the screws.

Tighten

Tighten the sunshade screws to 3 N·m (27 lb in).

4. Install the sunshade bracket cover.