



11. With the aid of an assistant (2), dry fit the window (1) to the opening in order to determine the correct position.



12. If equipped, ensure that the windshield locator pins are positioned into the locator slots on the upper pinch-weld flange.



13. Using masking tape in order to mark the locations (1) of the window (2) in the opening.

14. Cut the masking tape in the center and remove the window from the opening.