


SONIC

Engine Coolant Fan Shroud Replacement (Gasoline)



Callout	Component Name
<p><b>Preliminary Procedure</b></p> <p>1. Remove the radiator surge tank. Refer to <a href="#">Radiator Surge Tank Replacement</a> .</p> <p>2. Unclip transmission cooler lines from shroud if equipped.</p> <p>3. Unclip radiator surge tank outlet hose from fan shroud.</p> <p>4. Disconnect any electrical connectors from the fan shroud.</p>	
1	<p>Engine Coolant Fan Shroud</p> <p><b>Tip</b> Unclip engine coolant fan shroud from radiator.</p>