


Body Lock Pillar Upper Trim Panel Replacement (Hatchback)



Callout	Component Name
<p>Preliminary Procedure</p> <p>Disable the SIR system. Refer to SIR Disabling and Enabling .</p>	
1	Inflatable Restraint Airbag Cover
2	Body Lock Pillar Upper Trim Panel Fastener Caution: Refer to Fastener Caution .
3	Body Lock Pillar Upper Trim Panel Assembly Procedure 1. Grasp the molding and pull outward to disengage the integral retainers. 2. Disconnect the electrical connector, if equipped.