


Rear Compartment Lid Hinge Torque Rod Replacement



Callout	Component Name
<p>Warning: Refer to Hood Hold-Open Device Warning .</p> <p>Preliminary Procedure</p> <p>Open and support the rear compartment lid.</p> <p>Special Tools</p> <p>BO-125 Torque Rod Lifter</p> <p>For equivalent regional tools, refer to Special Tools .</p>	
1	<p>Rear Compartment Lid Hinge Torque Rod– Right Side</p> <p>Note: Only use the special tool to remove and install the rear compartment lid hinge torque rod.</p>
2	<p>Rear Compartment Lid Hinge Torque Rod– Left Side</p> <p>Note: Only use the special tool to remove and install the rear compartment lid hinge torque rod.</p>