


Front Floor Console Cover Replacement (Automatic Transmission)



Callout	Component Name
1	<div>Front Floor Console Cover Assembly</div> <div>Procedures</div> <div><div>1. Apply the parking brake.</div><div>2. Move the shifter from “Park” to the “Neutral” position.</div><div>3. Use a flat-bladed plastic trim tool in order to release the retainers securing the console cover to the console assembly.</div><div>4. Disconnect the electrical connections.</div><div>5. When replacing the console cover, transfer all necessary components.</div></div>