


Shoulder Belt Replacement - Rear (Sedan)



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the rear window panel trim. Refer to Rear Window Panel Trim Replacement .</p>	
1	<p>Rear Seat Shoulder Belt Anchor Plate Fastener</p> <p>Caution: Refer to Fastener Caution .</p> <p>Tighten 45 N·m (33 lbft)</p>
2	<p>Rear Seat Shoulder Belt Retractor Fastener</p> <p>Tighten 45 N·m (33 lbft)</p>
3	<p>Rear Seat Shoulder Belt</p>