


Front Floor Console Replacement



Callout	Component Name
<p>Preliminary Procedures</p> <p>1. Remove the right and left front floor console extensions. Refer to Front Floor Console Extension Replacement - Right Side and Front Floor Console Extension Replacement - Left Side .</p> <p>2. Remove the front floor console cover assembly. Refer to Front Floor Console Cover Replacement .</p>	
1	<p>Front Floor Console Fasteners (Qty: 6)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Procedure</p> <p>Move the front seats to the full forward position to access the front floor console rear fasteners.</p>
2	<p>Front Floor Console</p> <p>Procedures</p> <p>1. Disconnect the electrical connections.</p> <p>2. When replacing the console, transfer all necessary components.</p>