


Sunroof Housing Front Drain Hose Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>It is only necessary to lower the headliner. Only do those steps in the headliner replacement procedure that will lower the headliner enough to gain access to the part. Refer to Headlining Trim Panel Replacement .</p>	
1	Sunroof Housing Front Drain Hose Retainers (Qty: 4)
2	<div>Sunroof Housing Front Drain Hose</div> <div>Procedure</div> <div><div>1. Remove the sunroof housing front drain hose and grommet from plenum.</div><div>2. Water test the vehicle before installing the headliner to ensure no water leaks.</div></div>