



- 11. Insert the assembly into the case (5).
- 12. With the lock cylinder assembly installed in the case (5), install the retainer (6) and stake the retainer in place using a small punch and hammer to peen the case material onto the exposed ends of the installed retainer (6).
- 13. Insert the key into the lock and function the lock to check for proper assembly and smooth operation.