



SONIC

Installation Procedure



1. Install the drive belt (1).



2. Release tension to the tensioner by rotating counterclockwise (1).
- Note:** Allow tensioner to slide back slowly.
3. Remove *EN 6349* pin (2).
4. Apply tension to the tensioner clockwise (1).
5. Install the front wheelhouse liner inner front extension. Refer to [Front Wheelhouse Liner Inner Front Extension Replacement](#) .
6. Install the power steering pump belt, if equipped. Refer to [Power Steering Pump Belt Replacement](#) .