





12. Apply glass prep clear to the area approximately 10–16 mm (3/8–5/8 in) around the entire perimeter of the window inner surface.  
Immediately wipe the glass primed area using a clean, lint-free cloth.



13. Apply bonded-glass primer and let dry per auto-adhesive instructions by the manufacturer's.



14. Apply the auto-adhesive primer-application (2) around the perimeter of the window (1) per auto-adhesive instructions by the manufacturer's.  
15. Apply the glass primer black to the same areas (2) that glass prep clear was applied.  
16. Allow the glass primer to dry per auto-adhesive instructions by the manufacturer's.