


SONIC

Radio Replacement (Without US8)



Callout	Component Name
<p><b>Preliminary Procedure</b></p> <p>Remove the instrument panel center molding. Refer to <a href="#">Instrument Panel Center Molding Replacement</a> .</p>	
1	<p>Radio Bolts (Qty: 4)</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p>
2	<p>Radio Assembly</p> <p><b>Procedure</b></p> <p>1. Disconnect the electrical connections. 2. Refer to <a href="#">Control Module References</a> for programming and setup information.</p>