



SONIC

Installation Procedure



1. Install the radiator inlet hose (3).
2. Install the radiator inlet hose clamp (4) to the radiator (5) using the *BO-38185* pliers .
3. Install the radiator inlet hose clamp (2) to the thermostat housing (1) using the *BO-38185* pliers .
4. install the radiator inlet hose (3) into the retainer clip.



5. Install the electronic control module (1) to the battery tray.
6. Install the radiator surge tank. Refer to [Radiator Surge Tank Replacement](#) .
7. Fill the coolant system. Refer to [Cooling System Draining and Filling](#)