


Outside Rearview Mirror Replacement (Power)



Callout	Component Name
<p><b>Preliminary Procedures</b></p> <p>1. Remove the front side door upper front trim panel. Refer to <a href="#">Front Side Door Upper Front Trim Panel Replacement</a> .</p> <p>2. Remove the outside rearview mirror bolt access hole on the front side door trim panel.</p>	
1	<p>Outside Rearview Mirror Fastener (Qty: 3)</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p> <p><b>Procedure</b></p> <p>Disconnect the electrical connector.</p> <p><b>Tighten</b> 10N·m (89lbin)</p>
2	<p>Outside Rearview Mirror</p> <p><b>Procedure</b></p> <p>Inspect the outside mirror for proper operation before installing the door trim panel.</p>