

SONIC


# Power Steering Pump Belt Replacement

## Special Tools

*CH 49800* Installer Power Steering Pump Belt


For equivalent regional tools, refer to [Special Tools](#) .

## Removal Procedure



1. Cut the power steering pump belt (2) with a appropriate cutting tool at position (1).
2. Remove the power steering pump belt (2)

## Installation Procedure



1. Relieve the tension of the drive belt (1). Refer to [Drive Belt Replacement](#) .
2. Install *CH-49800* installer (3) on the power steering pump pulley.
3. Install NEW power steering belt (2) aligning pulley water pump.
4. Rotate the power steering pump pulley clockwise using hex wrench on the shaft power steering pump pulley.
5. Remove the *CH-49800* installer (3).
6. Install the drive belt. Refer to [Drive Belt Replacement](#)