


Dome Lamp Bezel Replacement



Callout	Component Name
1	<div>Dome Lamp Bezel</div> <div>Procedures</div> <div><div>1. Grasp the bezel assembly and pull downward to release the retainer clips securing the bezel assembly to the headliner.</div><div>2. Disconnect the electrical connections.</div></div>