



4. Loosely install the fasteners (1) securing the instrument panel tie bar assembly to the HVAC module.



5. Loosely install the bolts (1) securing the right and left instrument panel tie bar lower support brackets (2) to the front floor tunnel panel.



6. Loosely install the nut (1) securing the instrument panel tie bar to the brake pedal mounting bracket.