



Installation Procedure




1. Position the front stabilizer shaft (1) in the front suspension frame.

**Caution:** Refer to [Fastener Caution](#) .



2. Install the front stabilizer shaft insulator bolts and tighten to **22N·m (16lbft)**.



3. Lift the front suspension frame (1) into the proper position. Refer to [Drivetrain and Front Suspension Frame Replacement](#) .  
4. Install the lower control arm ball joint to steering knuckle bolts. Refer to [Lower Control Arm Replacement](#) .