


Hood Primary and Secondary Latch Replacement



Callout	Component Name
1	<div>Hood Primary and Secondary Latch Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution .</div> <div>Tighten 22N·m (16lbft)</div>
2	<div>Hood Primary and Secondary Latch</div> <div>Procedure</div> <div>Disconnect the release cable from the hood primary latch.</div>