


Hood Replacement



Callout	Component Name
<p><b>Preliminary Procedure</b></p> <p>Disconnect the windshield washer nozzle hose.</p>	
1	<p>Hood Hinge Nut (Qty: 4)</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p> <p><b>Procedure</b></p> <p>Mark the location of the hinge to the hood with a grease pencil to aid in alignment.</p> <p><b>Tighten</b> 22N·m (16lbft)</p>
2	<p>Hood</p> <p><b>Procedure</b></p> <p>1. Transfer parts as needed. 2. Adjust the hood if needed. Refer to <a href="#">Hood Adjustment</a> .</p>