



Installation Procedure



- 1. Install the heater outlet hose to the vehicle.
- 2. Install the heater outlet hose (2) to the engine.
- 3. Install the heater outlet hose clamp (1) at the engine using *BO-38185* Hose Clamp Pliers .



- 4. Install the heater outlet hose (2) to the heater core.
- 5. Connect the heater outlet hose quick connect fitting (1) at the heater core.
- 6. Fill the cooling system. Refer to [Cooling System Draining and Filling](#)