


- 2. Using the spring compressor (1), compress the front spring assembly (2) install the front strut spring mount nut.
- 3. Hand tighten the front suspension strut nut.

Caution: Refer to [Fastener Caution](#) .



Note: Use the proper size TORX® bit, hold the strut shaft.

- 4. Using the appropriate size socket (2) and the TORX® bit (1), tighten the front suspension strut nut to **65 N·m (48 lb ft)**.
- 5. Remove the front suspension strut from the spring compressor.
- 6. Install the front suspension strut to the vehicle. Refer to [Strut Assembly Removal and Installation](#) .