


Center Pillar Upper Trim Panel Replacement (Without AHU)



Callout	Component Name
<p><b>Preliminary Procedures</b></p> <p>1. Remove the center pillar lower garnish molding. Refer to <a href="#">Center Pillar Lower Trim Panel Replacement</a> .</p> <p>2. Remove the seat belt from the front seat. Refer to <a href="#">Driver or Passenger Seat Shoulder Belt Replacement</a> .</p>	
1	<p>Center Pillar Upper Trim Panel Assembly</p> <p><b>Procedure</b></p> <p>When replacing the center pillar upper trim panel, feed the seat belt through the panel.</p>