

SONIC

Radiator Inlet Hose Replacement (1.6L or 1.8L)


Special Tools

BO-38185 Hose Clamp Pliers


For equivalent regional tools, Refer to [Special Tools](#) .

Removal Procedure

1. Drain the cooling system. Refer to [Cooling System Draining and Filling](#) .



2. Remove the radiator inlet hose clamp (1) at the engine using *BO-38185* Hose Clamp Pliers .
3. Remove the radiator inlet hose (2) from the engine.



4. Remove the radiator inlet hose clamp (1) at the radiator using *BO-38185* Hose Clamp Pliers .
5. Remove the radiator inlet hose (2) from the radiator.
6. Remove the radiator inlet hose from the vehicle.