


Rear Seat Center Shoulder Belt Replacement (Sedan)



Callout	Component Name
<p><b>Preliminary Procedures</b></p> <p>Remove the rear seat cushion. Refer to <a href="#">Rear Seat Cushion Replacement</a> .</p>	
1	<p>Rear Seat Center Shoulder Belt Buckle Fastener</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p> <p><b>Tighten</b> 45 N·m (33 lbft)</p>
2	<p>Rear Seat Center Shoulder Belt</p>