


Rear Window Panel Trim Replacement (Sedan)



Callout	Component Name
<p>Preliminary Procedures</p> <p>1. Remove the body lock pillar upper trim panel. Refer to Body Lock Pillar Upper Trim Panel Replacement .</p> <p>2. Remove the body rear seat back trim panel. Refer to Body Rear Seat Back Trim Panel Replacement .</p>	
1	Rear Window Panel Trim Fastener (Qty: 2)
2	<p>Rear Window Panel Trim Assembly</p> <p>Procedure</p> <p>When replacing the rear window panel trim assembly, transfer all necessary components.</p>