


Installation Procedure



- 1. Position the console cover assembly (1) to the console assembly.
- 2. Feed the transmission control lever boot assembly thru the opening in the console cover assembly (1).



- 3. Snap the transmission control lever boot assembly (2) to the console cover (1) ensuring the retainer tabs lock the boot assembly to the cover.
- 4. Install the cover assembly to the console.