


Instrument Cluster Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>1. Remove the instrument panel cluster upper bezel. Refer to Instrument Cluster Upper Bezel Replacement .</p> <p>2. Remove the instrument panel steering column upper trim cover. Refer to Steering Column Upper Trim Cover Replacement .</p>	
1	<p>Instrument Cluster Fasteners (Qty: 3)</p> <p>Caution: Refer to Fastener Caution .</p>
2	<p>Instrument Cluster Assembly</p> <p>Procedure</p> <p>1. Disconnect the electrical connector.</p> <p>2. Refer to Control Module References for programming and set up information.</p>