


Front Seat Armrest Replacement



Callout	Component Name
1	<div>Front Seat Armrest Cover Zipper</div> <div><b>Procedure</b></div> <div>Open the zipper to access the front seat armrest mounting bolt and to remove the armrest cover</div>
2	<div>Front Seat Armrest Cover</div> <div><b>Procedure</b></div> <div>Slide the armrest cover off the armrest assembly.</div>
3	<div>Front Seat Armrest Mounting Bolt</div> <div><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</div> <div><b>Tighten</b> 45N·m (33lbft)</div>
4	<div>Front Seat Armrest Spring Washer</div>
5	<div>Front Seat Armrest Washer</div>
6	<div>Front Seat Armrest Assembly</div>