


Windshield Header Courtesy Lamp Replacement



Callout	Component Name
1	<div>Windshield Header Courtesy Lamp</div> <div>Procedures<div><div>1. Grasp the courtesy lamp assembly and pull downward to release the retainer clips securing the courtesy lamp assembly to the dome lamp bezel.</div><div>2. Disconnect the electrical connections.</div></div></div>