


9. Drill all factory welds (1). Note the number and location of welds for installation of the service assembly.



10. Remove the damaged body lock pillar inner reinforcement (1).



11. Locate and mark all the necessary factory welds of the rear wheelhouse outer panel.
12. Drill all factory welds (1). Note the number and location of welds for installation of the service assembly.