


Outside Remote Control Rearview Mirror Switch Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the front side door widow switch bezel. Refer to Front Side Door Window Switch Bezel Replacement .</p>	
1	<p>Outside Remote Control Rearview Mirror Switch Assembly</p> <p>Procedure</p> <p>1. Disconnect the electrical connector.</p> <p>2. Refer to Control Module References for programming and set up procedures.</p>