


Steering Wheel Horn Contact Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the steering wheel inflatable restraint module. Refer to Steering Wheel Inflatable Restraint Module Replacement .</p>	
1	<p>Steering Wheel Horn Contact Spring Retainer Bolt (Qty: 3)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Tighten 5.5 N·m(49 lb in)</p>
2	<p>Steering Wheel Horn Contact Assembly</p> <p>Procedure</p> <p>Disconnect the electrical connectors.</p>