



8. Measure up 1 inch from the door opening feature line (1) and mark a horizontal line.



9. Cut access window (1) in the center pillar outer.
10. Perform additional sectioning procedures as needed depending on damage to vehicle. Refer to [Rocker Outer Panel Sectioning](#) or [Front Hinge Pillar Body Sectioning](#) .



11. Locate and drill out all factory welds (1). Note the number and location of welds for installation of the service part.