


Fuel Tank Filler Door Latch Housing Replacement



Callout	Component Name
<p>Preliminary Procedures</p> <p>1. Remove the rear wheelhouse panel liner. Refer to Rear Wheelhouse Panel Liner Replacement .</p> <p>2. Remove the fuel tank filler door. Refer to Fuel Tank Filler Door Replacement .</p>	
1	<p>Fuel Tank Filler Door Latch Housing Retainer (Qty: 4)</p> <p>Procedure</p> <p>Release the 4 filler door latch housing retainers on the back of the housing.</p>
2	<p>Fuel Tank Filler Door Latch Housing</p> <p>Procedure</p> <p>Press the fuel tank filler housing outward from the fuel filler pipe and the quarter panel.</p>