


4. Position the service front wheelhouse front panel to the vehicle (1). Clamp the front wheelhouse in place.



5. When the service assembly is correctly positioned, plug weld accordingly (1).
6. Measure frequently to ensure proper fit and alignment.
7. Clean and prepare all welded surfaces.
8. Apply the sealers and anti-corrosion materials to the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#) .
9. Paint the repaired area. Refer to [Basecoat/Clearcoat Paint Systems](#) .
10. Install all related panels and components.
11. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
12. Enable the SIR system. Refer to [SIR Disabling and Enabling](#) .