



11. Remove the fasteners (1) securing the instrument panel tie bar assembly to the HVAC module.



- 12. Remove the bolts (1) securing the instrument panel tie bar assembly to the vehicle body.
- 13. Note the location and routing of the instrument panel wiring harness in order to ensure proper installation.
- 14. Support the HVAC module in order to prevent damage.
- 15. With the aid of an assistant remove the instrument panel tie bar assembly (2) from the vehicle.

Installation Procedure

- 1. With the aid of an assistant position the instrument panel tie bar assembly (2) into the vehicle.
- 2. Install the instrument panel wiring harness assembly to its in vehicle position as it was noted in the removal procedure.



3. Loosely install the bolts (1) securing the instrument panel tie bar assembly to the vehicle body.