



Installation Procedure




1. Position the front strut assembly (1) in the vehicle.



2. Install the NEW front strut nut (1) and the retaining plate (2).

Caution: Refer to [Fastener Caution](#) .



3. Using the CH35669 socket (2) and the proper size allen wrench, tighten the nut to **35 N·m (26 lb ft)**.