


SONIC

Radio Replacement (With US8)



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the instrument panel center molding. Refer to Instrument Panel Center Molding Replacement .</p>	
1	<p>Radio Bolts (Qty: 4)</p> <p>Caution: Refer to Fastener Caution .</p>
2	<p>Radio Assembly</p> <p>Procedure</p> <p>1. Disconnect the electrical connections. 2. Refer to Control Module References for programming and setup information.</p>