


Rear License Plate Lamp Replacement (Sedan)



Callout	Component Name
<p>Preliminary Procedure</p> <p>1. Insert a small flat-blade at the arrow location at the lamp housing edge.</p> <p>2. Push inward slightly and rotate downward.</p> <p>3. Pull the housing down far enough to access the lamp socket and electrical harness.</p>	
1	<p>Rear License Plate Lamp Socket</p> <p>Procedure</p> <p>Rotate the lamp socket a quarter turn and remove.</p>
2	<p>Rear License Plate Lamp</p>