



17. Install the window reveal molding (1). Refer to [Windshield Upper Reveal Molding Replacement](#) .



18. Use a cartridge-type caulking gun in order to apply a smooth, continuous bead.
Cut the applicator nozzle to provided a V cut to apply the auto-adhesive.



19. Use the edge of the window as a guide for the nozzle in order to apply the urethane adhesive (1) to the inner surface of the window (3).