


## Sunroof Window Height and Opening Fit Adjustment

**Note:** Correct adjustment cannot be achieved if the sunroof window is closed from vent position.

1. Cycle the sunroof window from full open to closed position.



**Note:** Do Not remove or lower headliner to access sunroof window screws.

2. Loosen the adjusting screws on the window.
3. Adjust the corners of the front window panel using the following guidelines:
  - Adjust the front of the sunroof window to0.0mm – 1.0mm (0.0in – 0.04in) below the top surface of the roof panel.
  - Adjust the rear center line of the sunroof window to2mm to 3mm (0 .08in to0.12in) below the top surface of the roof panel.

**Caution:** Refer to [Fastener Caution](#) .

4. Tighten the sunroof window adjustment screws to **5 N·m (44 lbin)**.
5. Cycle sunroof window through all positions.
6. Inspect the sunroof window adjustment. Adjust if necessary.