


Vehicle Certification, Tire Placard, Anti-Theft, and Service Parts ID Label


Certification Plate Location



The vehicle identification number (VIN) plate is attached to the top of the front end upper tie bar which is located under the radiator opening upper cover.

10 Matiz - Identification Plate Location

Tire Placard



The tire placard label is located on the driver side B- pillar and displays the following assessments:

- Tire size
- Tire pressure
 - Front
 - Rear
 - Various loading conditions