


Windshield Wiper Blade Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>1. Service Up and hold the wiper arm off the windshield when performing the wiper blade replacement.</p> <p>2. Pinch the two tabs on top of the wiper blade.</p> <p>3. Rotate the bottom edge of the wiper blade, downward, away from the wiper arm.</p> <p>4. Detach the wiper blade from the hook end of the windshield wiper arm.</p> <p>5. Carefully return the windshield wiper arm back to the glass until the new wiper blade is installed.</p>	
1	Windshield Wiper Blade Assembly