


Body Lock Pillar Upper Trim Panel Replacement (Sedan)



Callout	Component Name
<p>Preliminary Procedure</p> <p>1. Disable the SIR system. Refer to SIR Disabling and Enabling .</p> <p>2. Remove the body side trim panel. Refer to Body Side Trim Panel Replacement .</p>	
1	<p>Body Lock Pillar Upper Trim Panel Assembly</p> <p>Procedure</p> <p>Pull outward from the top front to disengage clips.</p>