


Shock Absorber Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>1. Raise and support the vehicle. Refer to Lifting and Jacking the Vehicle .</p> <p>2. Remove the tire and wheel assembly. Refer to Tire and Wheel Removal and Installation .</p>	
1	<p>Rear Shock Absorber Upper Bolt (Qty: 2)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Procedure</p> <p>Support the rear axle with a hydraulic jack.</p> <p>Tighten 58 N·m (43 lb ft)</p>
2	<p>Rear Shock Absorber Lower Bolt</p> <p>Tighten 120 N·m (89 lb ft)</p>
3	<p>Rear Shock Absorber Assembly</p>
4	<p>Shock Absorber Nut</p> <p>Tighten 25 N·m (18 lb ft)</p>
5	<p>Shock Absorber Mount</p>