


Note: DO NOT cover the headlamp. This may cause excessive heat build up.

8. Turn ON the low beam headlamps. Block the light from projecting onto the screen from the passenger side headlamp.



9. Adjust the vertical aim screw (as shown by the arrow) of the headlamps to the specifications required by the state and the local authorities, or as shown in step number8.
10. Repeat the aiming procedure for the passenger side headlamp while blocking the light from projecting onto the screen from the driver side headlamp.
11. Turn the headlamps OFF.
12. Close the hood.