


Outside Rearview Mirror Replacement (Manual)



Callout	Component Name
<p>Preliminary Procedures</p> <p>1. Remove the front side door upper front trim panel. Refer to Front Side Door Upper Front Trim Panel Replacement .</p> <p>2. Remove the outside rearview mirror bolt access hole on the front side door trim panel.</p>	
1	<p>Outside Rearview Mirror Fastener (Qty: 3)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Tighten 10N·m (89lbin)</p>
2	<p>Outside Rearview Mirror</p> <p>Procedure</p> <p>1. Transfer the outside rearview mirror knob.</p> <p>2. Inspect the outside mirror for proper operation before installing the door trim panel.</p>